

AC Coupled Inverter

Installation and Operation Manual

www.aforeenergy.com



Version: T06020-02



Afore New Energy Technology (Shanghai) Co., Ltd.

T +86-21-54326236 F +86-21-54326136 E info@aforeenergy.com

Ad Building 7, No.333 Wanfang Rd, Minhang District, Shanghai, China. 201112



Afore New Energy Technology (Shanghai) Co., Ltd.

Contents

1. About This Manual	1
1.1 Scope of Validity	1
1.2 Target Group	1
2. Safety & Symbols	1
2.1 Safety Precautions	1
2.2 Explanations of Symbols	2
3. Introduction.	3
3.1 Basic Instruction	3
3.2 Operation Modes	4
3.2.1 Self-use	4
3.2.2 Charging First	5
3.2.3 Command charge and discharge	5
3.2.4 External EMS dispatch	5
3.2.5 EPS	6
3.2.6 Timed charge and discharge	6
3.2.6.1 AC Charge	6
3.2.6.2 Force Charge.	6
3.2.6.3 Force Discharge	6
3.2.6.4 Forbid discharge	6
4. Installation.	7
4.1 Pre-installation	7
4.1.1 Unpacking & Package List	7
4.1.2 Product Overview	8
4.1.3 Mounting Location	9
4.2 Mounting	11
4.3 Electrical Connection	12
4.3.1 Battery Connection.	13
4.3.1.1 BAT-CAN/RS485	16
4.3.1.2 BAT-NTC	16
4.3.2 AC Connection	17
4.3.3 Meter Connection	19
4.4 Communication Connection.	21
4.5 Earth Connection.	22

5. Operation	23
5.1 Control Panel	23
5.2 Menu Overview	24
5.3 Control Panel	24
5.3.1 Time	25
5.3.2 Safety	25
5.3.3 Lithium Battery	26
5.3.4 Lead Acid	26
5.3.5 Energy Management System	27
5.3.6 Timing Charging&Discharging	27
5.3.7 AC Timing Charging	28
5.3.8 Forced Charging	28
5.3.9 Forced Discharging	29
5.3.10 Meter	29
5.3.11 Protection Parameters	30
5.3.12 Communication Parameters	30
6. Power ON/OFF	31
6.1 Power ON	31
6.2 Power OFF	31
6.3 Restart	31
7. Maintenance & Trouble Shooting	31
7.1 Maintenance	31
7.2 Trouble Shooting	31
8. Specifications	42

1. About This Manual

1.1 Scope of Validity

This manual mainly describes the product information, guidelines for installation, operation, maintenance and troubleshooting. And this manual applies to Afore Single Phase AC Coupled Inverter.

AF1K-SL-0 AF1.5K-SL-0 AF2K-SL-0 AF2.5K-SL-0 AF3K-SL-0
AF3.6K-SL-0 AF4K-SL-0 AF4.6K-SL-0 AF5K-SL-0
AF5.5K-SL-0 AF6K-SL-0

Please keep this manual available all the time in case of any emergency.

1.2 Target Group

This manual is for qualified personnel. The tasks described in this manual must only be performed by qualified personnel.

2. Safety & Symbols

2.1 Safety Precautions

1. All work on the inverter must be carried out by qualified electricians.
2. Do not touch the inverter cover until 5 minutes after disconnecting both AC power supply.
3. Do not touch the inverter enclosure when operating, keep away from materials that may be affected by high temperatures.
4. Please ensure that the used device and any relevant accessories are disposed of in accordance with applicable regulations.
5. Afore inverter should be placed upwards and handled with care in delivery. Pay attention to waterproof. Do not expose the inverter directly to water, rain, snow or spray.
6. Alternative uses, modifications to the inverter not recommended. The warranty can become void if the inverter was tampered with or if the installation is not in accordance with the relevant installation instructions.

2.2 Explanations of Symbols

Afore inverter strictly comply with relevant safety standards. Please read and follow all the instructions and cautions during installation, operation and maintenance.



Danger of electric shock

The inverter contains fatal DC and AC power. All work on the inverter must be carried out by qualified personnel only.



Beware of hot surface

The inverter's housing may reach uncomfortably hot 60°C (140°F) under high power operation. Do not touch the inverter enclosure when operation.



Residual power discharge

Do not open the inverter cover until 5 minutes after disconnection both DC and AC power supply.



Important notes

Read all instructions carefully. Failure to follow these instructions, warnings and precautions may lead to device malfunction or damage.



Do not dispose of this device with the normal domestic waste.



Refer to manual before service.



CE mark


The inverter complies with the requirements of the applicable CE guidelines.

3. Introduction


3.1 Basic Instruction

The Afore AF-SL-0 AC Coupled inverters are designed to increase energy independence for homeowners. Energy management is based on time-of-use and demand charge rate structures, significantly reduce the amount of energy purchased from the public grid and optimize self-consumption.

Single Phase AC Coupled (Retro Fit)




Three Phase AC Coupled (Retro Fit)



3.2 Operation Modes

3.2.1 Self-use

A. Normal Mode




Priority: Load > Battery > Grid

This mode applies to situation that with low feed in subsidy and high electricity price.

1. Solar energy supply to the local load and charge to the battery first.
2. The excess power export to the public grid.
3. The wind turbines can be connected to the PV.
4. When off grid and the power is lacking, the generator will be turned on automatically.

3.2.2 Charging First



Priority: Battery > Load > Grid

This mode applies to situation with frequent power outages. When the public grid is off, enough energy can be supplied to the local load by the batteries.

Battery will be charged first, and discharge energy for the local load when the grid is off. It would be charged automatically.

3.2.3 Command charge and discharge

This mode the charging and discharging power operates according to the set parameters.

Within the power range that the battery can accept, run according to the set parameters, otherwise run the charge and discharge command according to the upper and lower limits of the battery.

3.2.4 External EMS dispatch

Priority: Battery charge command > Load > Grid

This mode power of charging and discharging is controlled by external EMS communication commands, which is suitable for occasions with centralized EMS.

To meet the power of EMS charging and discharging, the residual energy is fed back to the grid.

3.2.5 EPS

When the grid is suddenly off or abnormal, inverter will change to off grid status automatically. Energy from PV system and battery will supply the local load.

3.2.6 Timed charge and discharge

There are 4 types of timed charge and discharge control, each of which can be set for 3 time periods respectively. It operates according to these four types within the set time period, and resumes operation in the setting mode of 3.2.1~3.2.4 after the time expires.

3.2.6.1 AC Charge

During the set time period, the battery is charged with the set power. When the PV power is not enough, the power is drawn from the grid until the set SOC is reached, and the timing charging function is stopped.

3.2.6.2 Force Charge

During the set time period, the battery is charged with the set power, and the power is only drawn from the PV, not from the grid, and the timing charging function is stopped after the set SOC.

3.2.6.3 Force Discharge

During the set time period, discharge the battery with the set power until the set SOC stops the timed discharge function.

3.2.6.4 Forbid discharge

During the set time period, the PV power will give priority to the charging, not the load1.

4. Installation

4.1 Pre-installation


4.1.1 Unpacking & Package List

Unpacking

On receiving the inverter, please check to make sure the packing and all components are not missing or damaged. Please contact your dealer directly for supports if there is any damage or missing components.


Package List

Open the package, please check the packing list shown as below.




No.	Qty	Items	No.	Qty	Items
1	1	Hybrid Inverter	11	1	Grounding Terminal
2	1	Certificate Of Inspection	12	1	Wall Mounting Bracket
3	1	Quick Installation Instructions	13	1	Battery Connector
4	1	Warranty Card	14	1	Monitor Module
5	1	Monitoring Quick Installation Instructions	15	1	Communication Adapter
6	1	AC Waterproof Cover	16	3	Mounting Bracket Screw
7	4	AC Wiring Cover Screw	17	3	Plastic Expansion Tube
8	1	Security Screw	18	1	Smart Meter (Optional)
9	4	AC Wiring Terminal			
10	2	Communication Connectors			

4.1.2 Product Overview



Inverter Terminals




No.	Items	No.	Items
1	Battery Port	3	Conitor Module Port
2	Communication Port	4	AC Port & EPS Port


4.1.3 Mounting Location

The inverters are designed for indoor and outdoor installation (IP65), to increase the safety, performance and lifespan of the inverter, please select the mounting location carefully based on the following rules:


- The inverter should be installed on a solid surface, far from flammable or corrosion materials, where is suitable for inverter's weight and dimensions.
- The ambient temperature should be within $-25^{\circ}\text{C} \sim 60^{\circ}\text{C}$ (between -13°F and 140°F).
- The installation of inverter should be protected under shelter. Do not expose the inverter to direct sunlight, water, rain, snow, spray lightning, etc.



- The inverter should be installed vertically on the wall, or lean back on plane with a limited tilted angle. Please refer to below picture.





- Leave the enough space around inverter, easy for accessing to the inverter, connection points and maintenance.




4.2 Mounting


Step 1




Step 2




Step 3



4.3 Electrical Connection



Communication Adapter pin assignment



12345678

No.	COM1	COM2
1	NTC+	Meter 485A
2	NTC-	Meter 485B
3	Dry Contact	BAT 485A
4	Dry Contact	BAT CANH
5	DRM	BAT CANL
6	DRM	BAT 485B
7	485A	CTU
8	485B	CTN

4.3.1 Battery Connection


AF-SL-0 AC Coupled inverters are compatible with lithium battery. For lead acid battery or batteries with other brands, please confirm with local distributor or Afore for technical support.



Note:

Set battery type and manufacturer, please refer to Chapter 5.3. BMS(Battery Management System) communication is needed between inverter and battery.

Step 1




Note:

Battery cable suggestion Cross - section 8-10 AWG
Please make sure the battery polarities are correct.


Step 2

Pass the crimped battery harness through the waterproof connector and the cover.




Step 3

Insert the wire harness into the terminals according to "+" and "-" polarity, make the insulated terminals parallel with the terminals, the crimping screw torque is $2.0 \pm 0.1 \text{ N.m}$




Step 4

A "click" sound will be heard when the connector assembly is correct.



Step 5

Use an open-end wrench to tighten the waterproof lock.




Note:


Once the clamping nut is tightened, the nut will be locked.

Step 6


Insert the battery connector into the inverter, if hear a “click”, it means the battery connection is finished.



4.3.1.1 BAT-CAN/RS485



4.3.1.2 BAT-NTC



4.3.2 AC Connection

The AC terminal contains "GRID" and "EPS", GRID for load, and EPS for emergency load.

Before connecting, a separate AC breaker between individual inverter and AC input power is necessary. This will ensure the inverter be securely disconnected during maintenance and fully protected from current of AC input.

An extra AC breaker is needed for On-Grid connection to be isolated from grid when necessary. Below are requirements for the On-Grid AC-breaker.

Inverter Model	AC breaker specification
AF1-6K-SL-0	32A/200V/230V AC breaker



Note:


Qualified electrician will be required for the wiring.

Model	Wire Size	Cable (mm ²)	Torque value
1-6kW	8-10AWG	4-6	1.2N·m

Please follow steps for AC connection

- Connect DC protector or breaker first before connecting.
- remove insulation sleeve 11mm(0.5 inch) length, unscrew the bolts, insert the AC input wires according to polarities indicated on the terminal block and tighten the terminal screws.

Step 1



Note:

Cable suggestion
Cross-section 8-10AWG



Note:


The wiring terminals should be wrapped with insulation tape, otherwise it will cause a short circuit and damage the inverter.




Note:

The Max. power load connects to EPS port should not exceed the inverter's EPS Max. output power range.

Step 2



Step 3




Fix the AC wiring cover with cover screws


4.3.3 Meter Connection

Meters are used to detect current power direction of the local load and the grid. The output control function of the inverters will be activated based on the detected data.

Install the single-phase Meter



Install the three-phase Meter




4.4 Communication Connection

The monitoring module could transmit the data to the cloud server, and display the data on the PC, tablet and smart-phone.


Install the WIFI / Ethernet / GPRS / RS485 Communication

WIFI / Ethernet / GPRS / RS485 communication is applicable to the inverter. Please refer to "Communication Configuration Instruction" for detailed instruction.

Step 1



Step 2



Turn on the DC switch and AC circuit breaker, and wait until the LED indicator on the monitoring module flashes, indicating that the monitoring module is successfully connected.


4.5 Earth Connection



Note:

A second protective earth (PE) terminal should be connected to the inverter. This prevents electric shock if the original protective PE wire fails.


Step 1



Note:

Earth cable PE suggestion:
Cross-section (Copper) 4-6mm² / 10AWG

Step 2



Fix the grounding screw to the grounding connection of the machine housing.




Note:

Make sure the earth cables on the inverter and solar panel frame are separately.

5. Operation

5.1 Control Panel




No.	Items	No.	Items
1	LCD Display	5	ENT Touch Button
2	UP Touch Button	6	POWER LED Indicator
3	DOWN Touch Button	7	GRID LED Indicator
4	ESC Touch Button	8	FAULT LED Indicator

Sign	Power	Color	Explanation
POWER	ON	Green	The inverter is stand-by
	OFF		The inverter is power off
GRID	ON	Green	The inverter is feeding power
	OFF		The inverter is not feeding power
FAULT	ON	Red	Fault occurred
	OFF		No fault

5.2 Menu Overview

AF-SL hybrid inverter has a LCD for clearly operating, and menu of the LCD can be presented as following:



5.3 Control Panel

The setting is for AF-SL Hybrid inverter. Any doubts, please contact distributor for more details.

5.3.1 Time


Step1: "↵"Entry Menu;

Step2: "▲/▼"Up/Down Chose **System Param**, "↵" Confirm;

Step3: "▲/▼"Up/Down Chose **Date&Time**, "↵" Confirm;

Step4: "▲/▼"Set **Year/Mouth/Date/Hour/Minute/Second**, "↵" Confirm;

Step5: "←"Return.



5.3.2 Safety


Step1: "↵"Entry Menu;

Step2: "▲/▼"Up/Down Chose **System Param**, "↵" Confirm;

Step3: "▲/▼"Up/Down Chose **Safety**, "↵" Confirm;

Step4: "▲/▼"Chose Safety Rule (In the UK , Select **G98/G99**), "↵" Confirm;

Step5: "←"Return.



5.3.3 Lithium Battery

Step1: "↵"Entry Menu;


Step2: "▲/▼"Up/Down Chose **Running Param**, "↵"Confirm;

Step3: Password Confirm,▲/▼ Up/Down Chose "0", "↵"Confirm;

Step4: "▲/▼"Up/Down Chose **Lith (Lithium Battery)**, "↵" Confirm;

Step5: "▲/▼"Up/Down Chose **IvyHv/JBS48/JBSHV/HSD48/TaiSu/HSDHV/Afore/PYLON/Ivy48/**, "↵" Confirm;

Step6: "↶"Return.



5.3.4 Lead Acid

Step1: "↵"Entry Menu;


Step2: "▲/▼"Up/Down Chose **Running Param**, "↵"Confirm;

Step3: Password Confirm,▲/▼ Up/Down Chose "0", "↵"Confirm;

Step4: "▲/▼"Up/Down Chose **Lead** (Lead Acid Battery), "↵" Confirm;


Step5: "▲/▼"Up/Down Chose **Capacity/RComp/TComp/VChgMax**, "↵" Confirm;

Step6: "↶"Return.




5.3.5 Energy Management System

Step1: "↵"Entry Menu;
 Step2: "▲/▼"Up/Down Chose **Running Param**, "↵"Confirm;
 Step3: Password Confirm,▲/▼ Up/Down Chose "0", "↵"Confirm;
 Step4: "▲/▼"Up/Down Chose **EMS Param**, "↵" Confirm;
 Step5: "▲/▼"Up/Down Chose **EMS Mode**, "↵" Entry MES Setting;
 Step6: "▲/▼"Up/Down Chose **cmdChar/ExtEMS/SelfUse/ChgFst/SelfFst/Maintain** (Maintenance), "↵" Confirm;
 Step7: "↵"Return.




5.3.6 Timing Charging&Discharging

Step1: "↵"Entry Menu;
 Step2: "▲/▼"Up/Down Chose **Running Param**, "↵"Confirm;
 Step3: Password Confirm,▲/▼ Up/Down Chose "0", "↵"Confirm;
 Step4: "▲/▼"Up/Down Chose **EMS Param**, "↵" Confirm;
 Step5: "▲/▼"Up/Down Chose **Chg or Dischg Tim**, "↵" Entry MES Setting;
 Step6: "▲/▼"Up/Down Chose **Max /Mini Pwr /Max /Mini Volt/Max /Mini Curr**, "↵" Confirm;
 Step7: "↵"Return.




5.3.7 AC Timing Charging

Step1: "↵"Entry Menu;
 Step2: "▲/▼"Up/Down Chose **Running Param**, "↵"Confirm;
 Step3: Password Confirm,▲/▼ Up/Down Chose "0", "↵"Confirm;
 Step4: "▲/▼"Up/Down Chose **EMS Param**, "↵" Confirm;
 Step5: "▲/▼"Up/Down Chose **AC Chg(AC Forced Charging)**, "↵" Confrim;
 Step6: "▲/▼"Up/Down Chose **AC Chg(AC Forced Charging Switch On/Off)/MaxPpct** (Max power percentage)/**MaxSoc**(Max SOC)/**TimOn1**(Start time)/**TimOff1** (Stop time) /**TimeOn2**(Start time)/**TimOff2**(Stop time)/**TimOn3**(Start time)/**TimOff3**(Stop Time), "↵" Confirm, (Supporting max 3 stages charging&discharging time);
 Step7: "↵"Return.




5.3.8 Forced Charging

Step1: "↵"Entry Menu;
 Step2: "▲/▼"Up/Down Chose **Running Param**, "↵"Confirm;
 Step3: Password Confirm,▲/▼ Up/Down Chose "0", "↵"Confirm;
 Step4: "▲/▼"Up/Down Chose **EMS Param**, "↵" Confirm;
 Step5: "▲/▼"Up/Down Chose **Force Chg**(Forced Charging setting), "↵" Confrim,
 Step6: "▲/▼"Up/Down Chose **Force Chg**(Forced Charging Switch On/Off)/**PForce** (Max power percentage)/**MaxSoc**(Max SOC)/**TimOn1**(Start time)/**TimOff1** (Stop time) /**TimeOn2**(Start time)/**TimOff2**(Stop time)/**TimOn3**(Start time)/**TimOff3**(Stop Time), "↵" Confirm, (Supporting max 3 stages charging&discharging time);
 Step7: "↵"Return.




5.3.9 Forced Discharging

Step1: “↵”Entry Menu;
 Step2: “▲/▼”Up/Down Chose **Running Param**, “↵”Confirm;
 Step3: Password Confirm, ▲/▼ Up/Down Chose “0”, “↵”Confirm;
 Step4: “▲/▼”Up/Down Chose **EMS Param**, “↵” Confirm;
 Step5: “▲/▼”Up/Down Chose **Force DChg**(Forced Charging setting), “↵” Confirm,
 Step6: “▲/▼”Up/Down Chose **Force DChg**(Forced Charging Switch On/Off)/**PForce** (Max power percentage)/**MaxSoc**(Max SOC)/**TimOn1**(Start time)/**TimOff1** (Stop time) /**TimeOn2**(Start time)/**TimOff2**(Stop time)/**TimOn3**(Start time)/**TimOff3**(Stop Time), “↵” Confirm, (Supporting max 3 stages charging&discharging time);
 Step7: “↶”Return.



5.3.10 Meter

Step1: “↵”Entry Menu;
 Step2: “▲/▼”Up/Down Chose **Running Param**, “↵”Confirm;
 Step3: Password Confirm, ▲/▼ Up/Down Chose “0”, “↵”Confirm;
 Step4: “▲/▼”Up/Down Chose **Meter param**, “↵” Confirm;
 Step5: “▲/▼”Up/Down Chose **No Meter / CT/ Meter**, “↵” Confirm,
 Step6: if select **Meter**, “▲/▼” Up/Down chose **Afore / Afore3 / UKOB / User2**;
 Step7: if select **CT**, “▲/▼” set CT gains,
 Step8: “↶”Return.



5.3.11 Protection Parameters


Step1: “↵”Entry Menu;

Step2: “▲/▼”Up/Down Chose **Protection Param**, “↵”Confirm;

Step3: Password Confirm, ▲/▼ Up/Down Chose “0”, “↵”Confirm;

Step4: “▲/▼”Up/Down Chose **ISOChk / GfciChk / V.max / V.min / F.max / F.min**, “↵” Confirm;

Step7: “↶”Return.



5.3.12 Communication Parameters

Step1: “↵”Entry Menu;

Step2: “▲/▼”Up/Down Chose **Communication Param**, “↵”Confirm;

Step3: “▲/▼” Up/Down Chose **Wifi**, “↵”Confirm;

Step4: “▲/▼”Up/Down Chose **Wifi Addr** (default value “1”), “↵” Confrim;


Step5: “▲/▼” Up/Down Chose **Wifi Prot** (Wifi protocol: “**Modbus / SunSpec**”); “↵” Confirm;

Step6: “▲/▼” Up/Down, if chose **parallel** (Multi-inverter parallel working), “↵” Confirm;

Step7: Under **P Addr**, “▲ / ▼” Up/Down chose inverter number of parallel working, “↵” Confirm;

Step8: “▲/▼” Up/Down chose **P Baud**, “↵” Confirm;

Step9: “↶”Return.



6. Power ON/OFF

Please check the following requirements before testing:

- Installation location is suitable according to Chapter 4.1.3.
- All electrical wires are connected tightly, including PV modules, battery and AC side(Such as the grid side, EPS side, Gen side).
- Earth line and Smart meter/CT line are connected.
- AF-DF hybrid inverters should be set according to the required local grid standard.
- More information please contact with Afore or distributors.

6.1 Power ON

- Turn on DC switch.
- After LCD lighting, hybrid inverter should be set following Chapter 5.3 at the first time.
- When inverter running under normal mode, Running indicator will light up(Ref. to Chapter 5.1).

6.2 Power OFF

- Turn off DC switch (in hybrid inverter) and all extra-breaker.



Note:

Hybrid inverter should be restarted after 5 minutes.

6.3 Restart

Restart Hybrid inverter, please follow steps as below:

- Shutdown the inverter Ref. to Chapter6.2.
- Start the inverter Ref. to Chapter 6.1.

7. Maintenance & Trouble Shooting

7.1 Maintenance

Periodically maintenance are necessary, please follow steps as below.

- AC connection(Grid and EPS) : twice a year
- Battery connection: twice a year
- Earth connection: twice a year
- Heat sink: clean with dry towel once a year

7.2 Trouble Shooting

The fault messages are displayed when fault occurs, please check trouble shooting table and find related solutions.

Fault Code and Trouble Shooting

Type of Fault	Code	Name	Description	Recommend Solution
PV Fault	A01	PvConnectFault	PV connection type different from setup	<ul style="list-style-type: none"> • Check PV modules connection • Check PV Mode setup Ref. Chapter 5.3.
	A02	IsoFault	ISO check among PV panels/ wires and ground is abnormal.	<ul style="list-style-type: none"> • Check PV modules wires, those wires are soaked or damaged, and then carry out rectification. • If the fault occurs continuously and frequently, please ask help for local distributors.
	A03	PvAfcIFault	PV current arcing	<ul style="list-style-type: none"> • Check PV modules wires and connectors broken or loose connect, and then carry out rectification. • If the fault occurs continuously and frequently, please ask help for local distributors.
	A04	Pv1OverVoltFault	PV Voltage over	<ul style="list-style-type: none"> • Reconfiguration of PV strings, reduce the PV number of a PV string to reducing inverter PV input voltage. • Suggestion that contacting with local distributors.
	A05	Pv2OverVoltFault		
	A06	Pv3OverVoltFault		
	A07	Pv4OverVoltFault		
	A08	Pv5OverVoltFault		
	A09	Pv6OverVoltFault		
	A10	Pv7OverVoltFault		
	A11	Pv8OverVoltFault		
	A12	Pv9OverVoltFault		
	A13	Pv10OverVoltFault		
	A14	Pv11OverVoltFault		
	A15	Pv12OverVoltFault		
	A16	PV1ReverseFault	PV(+) and PV(-) reversed Connection	<ul style="list-style-type: none"> • Check PV(+) and PV(-) Connect whether reversed or not. • If reversed, make correction.
	A17	PV2ReverseFault		
	A18	PV3ReverseFault		
	A19	PV4ReverseFault		
	A20	PV5ReverseFault		
	A21	PV6ReverseFault		

Type of Fault	Code	Name	Description	Recommend Solution
PV Fault	A22	PV7ReverseFault		
	A23	PV8ReverseFault		
	A24	PV9ReverseFault		
	A25	PV10ReverseFault		
	A26	PV11ReverseFault		
	A27	PV12ReverseFault		
	A33	Pv1AbnormalFault	PV(+) and PV(-) reversed Connection	<ul style="list-style-type: none"> • Check PV modules partial occlusion or cells damaged. • Check PV module wires and connectors broken or loose connect, then repair it.
	A34	Pv2AbnormalFault		
	A35	Pv3AbnormalFault		
	A36	Pv4AbnormalFault		
	A37	Pv5AbnormalFault		
	A38	Pv6AbnormalFault		
	A39	Pv7AbnormalFault		
	A40	Pv8AbnormalFault		
	A41	Pv9AbnormalFault		
	A42	Pv10AbnormalFault		
	A43	Pv11AbnormalFault		
	A44	Pv12AbnormalFault		
	A45	Pv13AbnormalFault		
	A46	Pv14AbnormalFault		
	A47	Pv15AbnormalFault		
	A48	Pv16AbnormalFault		
	A49	Pv17AbnormalFault		
	A50	Pv18AbnormalFault		
	A51	Pv19AbnormalFault		
	A52	Pv20AbnormalFault		
	A53	Pv21AbnormalFault		
	A54	Pv22AbnormalFault		
	A55	Pv23AbnormalFault		
	A56	Pv24AbnormalFault		

Type of Fault	Code	Name	Description	Recommend Solution
Battery Fault	B01	PcsBatOverVoltFault	Battery voltage over or under	<ul style="list-style-type: none"> • Check inverters connected battery lines and connectors broken or loose connect. • Carry out rectification if broken or loose. • Checking battery voltage is abnormal or not, then maintenance or change new battery.
	B02	PcsBatUnderVoltFault		
	B03	PcsBatInsOverVoltFault		
	B04	PcsBatReversedFault	Bat. (+) and Bat. (-) are reversed.	<ul style="list-style-type: none"> • Check Bat.(+) and Bat.(-)connect reversed or not. • Make correction If reversed.
	B05	PcsBatConnectFault	Battery wires loose	<ul style="list-style-type: none"> • Check battery wires and connectors damage or loose connect. • Carry out rectification if break.
	B06	PcsBatComFault	Battery communication abnormal	<ul style="list-style-type: none"> • Check battery side communication wires damage or loose connect, and then carry out rectification. • Check battery is off or other abnormal, then Mastertenance battery or change new battery.
	B07	PcsBatTempSensorOpen	Battery temperature sensor abnormal	<ul style="list-style-type: none"> • Check battery temperature sensor and connected wires damage or not , then rectification or change new one.
	B08	PcsBatTempSensorShort		
	B09	BmsBatSystemFault	All these faults will be detected or reported by battery BMS.	<ul style="list-style-type: none"> • If specific fault high temperature or low temperature, then should change battery installed environment temperature. • Restart battery, maybe can working as normal. • If this fault occurs continuously and frequently, please ask help for local distributors.
	B10	BmsBatVolOverFault		
	B11	BmsBatVolUnderFault		
	B12	BmsCellVolOverFault		
	B13	BmsCellVolUnderFault		
	B14	BmsCellVolUnbanceFau		
	B15	BatChgCurOverFault		
	B16	BatDChgCurOverFault		
	B17	BatTemperatureOverFa		
	B18	BatTemperatureUnderF		
	B19	CelTemperatureOverFa		
	B20	CelTemperatureUnderF		
	B21	BatIsoFault		
	B22	BatSocLowFault		
	B23	BmsInterComFault		
	B24	BatRelayFault		

Type of Fault	Code	Name	Description	Recommend Solution
Battery Fault	B25	BatPreChaFault		
	B26	BmsBatChgMosFault		
	B27	BmsBatDChgMosFault		
	B28	BMSVolOVFault		
	B29	BMSVolLFault		
	B30	VolLockOpenFault		
	B31	VolLockShortFault		
	B32	ChgRefOVFault		
	C01	GridLossFault	Grid lost (islanding)	<ul style="list-style-type: none"> • Inverter will restart automatically when the grid return to normal. • Check inverter connected with grid connectors and cable normal or not.
	C02	GridUnbalanVoltFault	Grid Voltage unbalanced.	<ul style="list-style-type: none"> • The inverter will restart automatically when the grid three phase return to normal. • Check inverter connected with the grid connectors and wires normal or not. connectors and cable normal or not.
	C03	GridInstOverVoltFault	Grid instantaneous voltage over	<ul style="list-style-type: none"> • The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust protection parameters.
	C04	Grid10MinOverVoltFault	Grid voltage Over by 10 Minutes	<ul style="list-style-type: none"> • The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust 10 minutes protection voltage parameters.
	C05	GridOverVoltFault	Grid voltage over	<ul style="list-style-type: none"> • The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust voltage protection parameters.
	C06	GridUnderVoltFault	Grid voltage under	
	C07	GridLineOverVoltFault	Grid line voltage over	
	C08	GridLineUnderVoltFault	Grid line voltage under	
	C09	GridOverFreqFault	Grid Frequency over	<ul style="list-style-type: none"> • The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust frequency protection parameters.
	C10	GridUnderFreqFault	Grid Frequency under	<ul style="list-style-type: none"> • Contact with local distributor or required grid company adjust frequency protection parameters.

Type of Fault	Code	Name	Description	Recommend Solution
Off-grid Fault	D01	UpsOverPowerFault	Off-grid load over	<ul style="list-style-type: none"> • Reduce loads. • If sometimes overload, it can be ignored, when generation power enough can be recovery. • If those faults occurs continuously and frequently, please ask help for local distributors.
	D02	GridConflictFault	Grid connected to Back-up terminal	<ul style="list-style-type: none"> • Check the off-grid port connection correct, disconnect both off-grid and grid ports.
	D03	GenOverVoltFault	GenOverVoltFault	<ul style="list-style-type: none"> • Adjust generator running parameters, make the output voltage, frequency in allowed range. • If this fault occurs continuously and frequently, please ask help for local distributors.
	D04	GenUnderVoltFault	GenUnderVoltFault	
	D05	GenOverFreqFault	GenOverFreqFault	
	D06	GenUnderFreqFault	GenUnderFreqFault	
DC Fault	E01	Pv1HwOverCurrFault	PV current over, triggered by hardware protection circuit	<ul style="list-style-type: none"> • Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	E02	Pv2HwOverCurrFault		
	E03	Pv3HwOverCurrFault		
	E04	Pv4HwOverCurrFault		
	E05	Pv5HwOverCurrFault		
	E06	Pv6HwOverCurrFault		
	E07	Pv7HwOverCurrFault		
	E08	Pv8HwOverCurrFault		
	E09	Pv9HwOverCurrFault		
	E10	Pv10HwOverCurrFault		
	E11	Pv11HwOverCurrFault		
	E12	Pv12HwOverCurrFault		
	E13	Pv1SwOverCurrFault	PV current over, triggered by Software logic.	<ul style="list-style-type: none"> • Power off, power on then restart. • If those faults occurs continuously and frequently, please ask help for local distributors.
	E14	Pv2SwOverCurrFault		
	E15	Pv3SwOverCurrFault		
	E16	Pv4SwOverCurrFault		
	E17	Pv5SwOverCurrFault		
	E18	Pv6SwOverCurrFault		
	E19	Pv7SwOverCurrFault		
	E20	Pv8SwOverCurrFault		

Type of Fault	Code	Name	Description	Recommend Solution
DC Fault	E21	Pv9SwOverCurrFault		
	E22	Pv10SwOverCurrFault		
	E23	Pv11SwOverCurrFault		
	E24	Pv12SwOverCurrFault		
	E33	Boost1SelfCheck(boost)Fault	PV boost circuit abnormal when self checking	<ul style="list-style-type: none"> • Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E34	Boost2SelfCheck(boost)Fault		
	E35	Boost3SelfCheck(boost)Fault		
	E36	Boost4SelfCheck(boost)Fault		
	E37	Boost5SelfCheck(boost)Fault		
	E38	Boost6SelfCheck(boost)Fault		
	E39	Boost7SelfCheck(boost)Fault		
	E40	Boost8SelfCheck(boost)Fault		
	E41	Boost9SelfCheck(boost)Fault		
	E42	Boost10SelfCheck(boost)Fault		
	E43	Boost11SelfCheck(boost)Fault		
	E44	Boost12SelfCheck(boost)Fault		
	E45	BusHwOverVoltFault	Bus voltage over	<ul style="list-style-type: none"> • Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E46	BusHwOverHalfVoltFault		
	E47	BusSwOverVoltFault		
	E48	BusSwOverHalfVoltFault		
	E49	BusSwUnderVoltFault	Bus voltage under as running	
	E50	BusUnbalancedFault	DC Bus voltage unbalanced	
	E51	BusBalBridgeHwOver-CurFault	Bus Controller current over	<ul style="list-style-type: none"> • Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E52	BusBalBridgeSwOver-CurFault		
	E53	BusBalBridgeSelf-CheckFault	Bus Controller abnormal when self checking	
	E54	BDCSwOverCurrFault	BiDC current over	<ul style="list-style-type: none"> • Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E55	BDCSwOverCurrFault		
	E56	BDCSelfCheckFault	BiDC abnormal as self checking	
	E57	BDCSwOverVoltFault	BiDC voltage over	
	E58	TransHwOverCurrFault	BiDC current over	

Type of Fault	Code	Name	Description	Recommend Solution
	E59	BDCFuseFault	BiDC fuse broken	• Change fuse.
	E60	BDCRelayFault	BiDC relay abnormal	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
AC Fault	F01	HwOverFault	All over current/ voltage by protection hardware	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	F02	InvHwOverCurrFault	Ac over current by protection hardware	
	F03	InvROverCurrFault	R phase current over	
	F04	InvSOverCurrFault	S phase current over	
	F05	InvTOverCurrFault	T phase current over	
	F06	GridUnbalanCurrFault	On-grid current unbalanced	
	F07	DclnjOverCurrFault	DC injection current over	
	F08	AcOverLeakCurrFault	Ac side leakage current over	• Check AC insulation and ground wires connect ground is well or not, then repair it. • Power off, then restart (Ref. Chapter8).. • If those fault occurs continuously and frequently, please ask help for local distributors.
	F09	PLLFault	PLL abnormal	• Power off, then restart (Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F10	GridRelayFault	Grid relay abnormal	
	F11	UpsRelayFault	Ups relay abnormal	
	F12	GenRelayFault	Generator relay abnormal	
	F13	Relay4Fault	Relay4 abnormal	
	F14	UpsROverCurrFault	Off-grid output current over	• When off-grid the load start impulse current is over, reduce the start impulse current load. • Power off, then restart (Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F15	UpsSOverCurrFault		
	F16	UpsTOverCurrFault		
	F17	GenROverCurrFault	Generator current over	• Check generator output voltage, frequency is stability, and adjust generator. • Power off, then restart(Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F18	GenSOverCurrFault		
	F19	GenTOverCurrFault		
	F20	GenReversePowerFault	Active power injected to generator	

Type of Fault	Code	Name	Description	Recommend Solution
AC Fault	F21	UpsOverVoltFault	Off-grid output voltage over or under	<ul style="list-style-type: none">• Power off, then restart (Ref. Chapter8).• If those faults occurs continuously and frequently, please ask help for local distributors.
	F22	UpsUnderVoltFault		
	F23	UpsOverFreqFault	Off-grid output frequency over or under	
	F24	UpsUnderFreqFault		
	F25	DclnjOverVoltFault	Off-grid DC injection voltage over	
System Fault	G01	PV1CurAdChanFault	Sampling hardware abnormal	<ul style="list-style-type: none">• Power off, then restart (Ref. Chapter8).• If those faults occurs continuously and frequently, please ask help for local distributors.
	G02	PV2CurAdChanFault		
	G03	PV3CurAdChanFault		
	G04	PV4CurAdChanFault		
	G05	PV5CurAdChanFault		
	G06	PV6CurAdChanFault		
	G07	PV7CurAdChanFault		
	G08	PV8CurAdChanFault		
	G09	PV9CurAdChanFault		
	G10	PV10CurAdChanFault		
	G11	PV11CurAdChanFault		
	G12	PV12CurAdChanFault		
	G13	BDCCurrAdChanFault		
	G14	TransCurAdChanFault		
	G15	BalBrigCurAdChanFault		
	G16	RInvCurAdChanFault		
	G17	SInvCurAdChanFault		
	G18	TInvCurAdChanFault		
	G19	RInvDciAdChanFault		
	G20	SInvDciAdChanFault		
	G21	TInvDciAdChanFault		
	G22	LeakCurAdChanFault		
	G23	VoltRefAdChanFault		
	G24	UpsRCurAdChanFault		

Type of Fault	Code	Name	Description	Recommend Solution
System Fault	G25	UpsSCurAdChanFault		
	G26	UpsTCurAdChanFault		
	G27	GenRCurAdChanFault		
	G28	GenSCurAdChanFault		
	G29	GenTCurAdChanFault		
	G30	UpsRDcvAdChanFault		
	G31	UpsSDcvAdChanFault		
	G32	UpsTDcvAdChanFault		
	G37	TempAdChanFault	All temperature sensors abnormal	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	G38	VoltAdConflictFault	The sample value of PV, battery and BUS voltage inconsistent	
	G39	CPUAdConflictFault	The sample value between master CPU and slaver CPU inconsistent	
	G40	PowerCalcConflictFault	Power value between PV, battery and AC output inconsistent	
	G41	EnvirOverTempFault	Installation environment temperature over or low	• Change or improve the installation environment temperature, make running temperature suitable. • Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	G42	EnvirLowTempFault		
	G43	CoolingOverTempFault	Cooling temperature over or low	
	G44	CoolingLowTempFault		
	G45	OverTemp3Fault	Temperature3 over or low	
	G46	LowTemp3Fault		
	G47	CpuOverTempFault	CPU temperature over	
G48	ModelConflictFault	Version conflict with inverter	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.	
Inner Warning	I01	InterFanWarning	Fan abnormal	• Remove foreign matter logged in fan. • If those faults occurs continuously and frequently, please ask help for local distributors.
	I02	ExterFanWarning		
	I03	Fan3Warning		

Type of Fault	Code	Name	Description	Recommend Solution
Inner Warning	I04	EnvirTempAdChan-Warning	Some temperature sensors abnormal	<ul style="list-style-type: none"> The warnings are not matter influence. Power off, then restart (Ref. Chapter8). If those faults occurs continuously and frequently, please ask help for local distributors.
	I05	CoolingTempAdChan-Warning		
	I06	Temp3AdChanWarning		
	I07	ExtFlashComWarning	Flash abnormal	<ul style="list-style-type: none"> Power off, then restart (Ref. Chapter8). If this those faults continuously and frequently, please ask help for local distributors.
	I08	EepromComWarning	Eeprom abnormal	
	I09	SlaveComWarning	Communication between slaver CPU and master CPU abnormal	
	I10	HmiComWarning	HMI abnormal	
	I11	FreqCalcConflictWarning	Frequency value abnormal	
	I12	UnsetModel	Running model is not initial	<ul style="list-style-type: none"> Contact with local distributor.
Outside Warning	J01	MeterComWarning	Meter/CT abnormal	<ul style="list-style-type: none"> Check the smart meter model, connection or connectors are correct, any loose. if abnormal, repair or change. Power off, then restart (Ref. Chapter8). If those faults occurs continuously and frequently, please ask help for local distributors.
	J02	MeterConnectWarning	Wires connecting type of meter wrong	<ul style="list-style-type: none"> Check Meter/CT connection, installed place, and installed direction. if abnormal, re-installation. Power off, then restart (Ref. Chapter8). If this those faults continuously and frequently, please ask help for local distributors.
	J03	SohWarning	Battery SOH low	<ul style="list-style-type: none"> Contact with Battery manufacturer.
	J04	GndAbnormalWarning	Earth impedance over by cable loose and so on	<ul style="list-style-type: none"> Check earth line connection or earth connecting impedance. if abnormal, then adjust it. Power off, then restart (Ref. Chapter8). If this those faults continuously and frequently, please ask help for local distributors.
	J05	ParallelComWarning	Communication between master inverter and slaver ones abnormal in parallel mode	<ul style="list-style-type: none"> Check parallel connect communication wires damage, connectors loose, connect port correct or not. if not, then adjust it. Power off, then restart (Ref. Chapter8). If this those faults continuously and frequently, please ask help for local distributors.

8. Specifications

Battery	AF1K-SL-0	AF1.5K-SL-0	AF2K-SL-0	AF2.5K-SL-0
Max. Charge/Discharge Power (kW)	1	1.5	2.0	2.5
Max. Charge/Discharge Current (A)	25	40	50	63
Battery Normal Voltage (V)	51.2			
Battery Voltage Range (V)	40 - 60			
Battery Type	Li-ion/lead-acid etc.			
AC Grid	AF1K-SL-0	AF1.5K-SL-0	AF2K-SL-0	AF2.5K-SL-0
Max Continuous Current (A)	5.0	7.0	10.0	12.0
Max Continuous Power (kVA)	1.0	1.5	2.0	2.5
Nominal Grid Current(A)	4.6 / 4.4	6.9 / 6.6	9.1 / 8.7	11.4 / 10.9
Nominal Grid Voltage (V)	198 to 242 @ 220 / 207 to 253 @ 230			
Nominal Grid Frequency (Hz)	50 / 60			
Power Factor	0.999 (Adjustable from 0.8 overexcited to 0.8 underexcited)			
Current THD (%)	< 3			
AC Load Output	AF1K-SL-0	AF1.5K-SL-0	AF2K-SL-0	AF2.5K-SL-0
Max Continuous Current (A)	5.0	7.0	10.0	12.0
Max Continuous Power (kVA)	1.0	1.5	2.0	2.5
Max Peak Current (A) (10min)	6.9 / 6.6	10.5 / 10.0	13.7 / 13.1	17.1 / 16.4
Max Peak Power (kVA) (10min)	1.5	2.3	3.0	3.75
Nominal AC Current (A)	4.6 / 4.4	6.9 / 6.6	9.1 / 8.7	11.4 / 10.9
Nominal AC Voltage L-N (V)	220 / 230			
Nominal AC Frequency (Hz)	50 / 60			
Switching Time (s)	Seamless			
Voltage THD (%)	< 3			
Efficiency	AF1K-SL-0	AF1.5K-SL-0	AF2K-SL-0	AF2.5K-SL-0
Max. Efficiency (%)	97.6			
Bat. between AC Efficiency (%)	96.8			
Protection	AF1K-SL-0	AF1.5K-SL-0	AF2K-SL-0	AF2.5K-SL-0
Over Current/Voltage Protection	Yes			
Anti-Islanding Protection	Yes			
AC Short Circuit Protection	Yes			
Residual Current Detection	Yes			
Ground Fault Monitoring	Yes			
Insulation Resister Detection	Yes			
Enclosure Protect Level	IP65 / NEMA4X			
General Data	AF1K-SL-0	AF1.5K-SL-0	AF2K-SL-0	AF2.5K-SL-0
Dimensions (L x W x H, mm)	513 x 370 x 192			
Weight	17			
Topology	Transformer			
Cooling	Intelligent Fan			
Relatively Humidity	0 - 100 %			
Operating Temperature Range (°C)	- 25 to 60			
Operating Altitude (m)	< 4000			
Noise Emission (dB)	< 25			
Standby Consumption (W)	< 10			
Mounting	Wall Bracket			
Communication with RSD	SUNSPEC			
Display & Communication Interfaces	LCD, LED, RS485, CAN, Wi-Fi, GPRS, 4G			
Certification & Approvals	NRS97, G98/G99, EN50549-1, C10/C11, AS 4777, VDE-AR-N4105, VDE0126, IEC62040, IEC62109-1, IEC62109-2			
EMC	EN61000-6-2, EN61000-6-3			

Battery	AF3K-SL-0	AF3.6K-SL-0	AF4K-SL-0	AF4.6K-SL-0
Max. Charge/Discharge Power (kW)	3.0	3.6	4.0	4.6
Max. Charge/Discharge Current (A)	80	80	80	80
Battery Normal Voltage (V)	51.2			
Battery Voltage Range (V)	40 - 60			
Battery Type	Li-ion/lead-acid etc.			
AC Grid				
Max Continuous Current (A)	14.0	17.0	19.0	22.0
Max Continuous Power (kVA)	3.0	3.6	4.0	4.6
Nominal Grid Current(A)	13.7 / 13.1	16.4 / 15.7	18.2 / 17.4	21.0 / 20.0
Nominal Grid Voltage (V)	198 to 242 @ 220 / 207 to 253 @ 230			
Nominal Grid Frequency (Hz)	50 / 60			
Power Factor	0.999 (Adjustable from 0.8 overexcited to 0.8 underexcited)			
Current THD (%)	< 3			
AC Load Output	AF3K-SL-0	AF3.6K-SL-0	AF4K-SL-0	AF4.6K-SL-0
Max Continuous Current (A)	14.0	17.0	19.0	22.0
Max Continuous Power (kVA)	3.0	3.6	4.0	4.6
Max Peak Current (A) (10min)	20.5 / 19.6	24.6 / 23.5	27.3 / 26.1	31.4 / 30.0
Max Peak Power (kVA) (10min)	4.5	5.4	6.0	6.9
Nominal AC Current (A)	13.7 / 13.1	16.4 / 15.7	18.2 / 17.4	21.0 / 20.0
Nominal AC Voltage L-N (V)	220 / 230			
Nominal AC Frequency (Hz)	50 / 60			
Switching Time (s)	Seamless			
Voltage THD (%)	< 3			
Efficiency				
Max. Efficiency (%)	97.6			
Bat. between AC Efficiency (%)	96.8			
Protection	AF3K-SL-0	AF3.6K-SL-0	AF4K-SL-0	AF4.6K-SL-0
Over Current/Voltage Protection	Yes			
Anti-Islanding Protection	Yes			
AC Short Circuit Protection	Yes			
Residual Current Detection	Yes			
Ground Fault Monitoring	Yes			
Insulation Resister Detection	Yes			
Enclosure Protect Level	IP65 / NEMA4X			
General Data	AF3K-SL-0	AF3.6K-SL-0	AF4K-SL-0	AF4.6K-SL-0
Dimensions (L x W x H, mm)	513 x 370 x 192			
Weight	17			
Topology	Tranformer			
Cooling	Intelligent Fan			
Relatively Humidity	0 - 100 %			
Operating Temperature Range (°C)	- 25 to 60			
Operating Altitude (m)	< 4000			
Noise Emission (dB)	< 25			
Standby Consumption (W)	< 10			
Mounting	Wall Bracket			
Communication with RSD	SUNSPEC			
Display & Communication Interfaces	LCD, LED, RS485, CAN, Wi-Fi, GPRS, 4G			
Certification & Approvals	NRS97, G98/G99, EN50549-1, C10/C11, AS 4777, VDE-AR-N4105, VDE0126, IEC62040, IEC62109-1, IEC62109-2			
EMC	EN61000-6-2, EN61000-6-3			